


33" Snow Blower Track Drive



⚠ WARNING



Please read and understand the product manual completely before assembly

- Check the parts list to make sure all parts are received.
- Wear safety goggles or other protective gear while assembling.
- Do not return products to dealers, who are not equipped to handle returns.

Missing parts or questions about assembly?

Email: cs@tmgindustrial.com

Or visit: tmgindustrial.com



Table of Contents

1. Introduction..... 2

2. Recycling and Disposal 2

3. Symbols 3

4. Safety 4

5. Contents Supplied 8

6. Assembly..... 9

7. Know Your Snow blower..... 13

8. Operation..... 22

9. Maintenance..... 25

10. Service 27

11. Troubleshooting 34

12. Exploded View & Parts List..... 36

1. Introduction

Your new snow blower will more than satisfy your expectations. It has been manufactured under stringent quality standards to meet superior performance criteria. You will find it easy and safe to operate, and with proper care, it will give you many years of dependable service.

Carefully read through this entire operator's manual before using your new snow blower. Take special care to heed the cautions and warnings.

Your snow blower has many features that will make your job faster and easier. Safety, performance, and dependability have been given to top priority in the development of this machine, making it easy to maintain and operate.

The Engine manufacturer is responsible for all engine-related issues with regards to performance, power rating, specifications, warranty and service. Please refer to the Engine Manufacturer's owner's/operator's manual, packed separately with your unit, for more information.

Specification

Item	Parameter
Model No.	TMG-GSBT33
Clearing Width	85 cm / 33 inch
Intake Height	58.5 cm / 23 inch
Auger Dia.	40.0 cm / 16 inch
Impeller Dia.	40.0 cm / 16 inch
Speed	6F + 2R

2. Recycling and Disposal

This marking indicates that this product should not be disposed of with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or check with your local authority or local stores for advice on environmentally safe recycling.



3. Symbols

The rating plate on your machine may show symbols. These represent important information about the product or instructions on its use.



Read these instructions for use carefully.



Wear eye protection.
Wear hearing protection.



Wear safety footwear.



Keep bystanders away.



Stop engine and remove ignition key prior to leaving the operator's position.



Only use clean-out tool to clear blockage. Never use your hands.



It is forbidden to remove or tamper with the protection devices and safety devices.



Do not smoke or have open flames.



Do not touch a hot muffler, gear housing or cylinder.



Stop engine, remove key, read manual before making any repairs or adjustments.



Keep hands out of the inlet and discharge openings while machine is running.



Stay away from rotating augers.



Never direct discharge towards persons or property.



Do not stare at the headlight. Risk of damage to eyesight.

4. Safety

4.1 General Safety Rules

Understand your machine

Allow operation only by properly trained adult, never children.

Read and understand the operator's manual and labels affixed to the machine. Learn its application and limitations as well as the specific potential hazards peculiar to it.

Be thoroughly familiar with the controls and their proper operation. Know how to stop the machine and disengage the controls quickly.

Make sure to read and understand all the instructions and safety precautions as outlined in the Engine Manufacturer's Manual, packed separately with your unit. Do not attempt to operate the machine until you fully understand how to properly operate and maintain the Engine and how to avoid accidental injuries and/or property damage.

Work area

Never start or run the engine inside a closed area. The exhaust fumes are dangerous, containing carbon monoxide, an odorless and deadly gas. Operate this unit only in a well ventilated outdoor area.

Never operate the machine without good visibility or light.

Never operate the machine on a steep slope.

Personal safety

Do not operate the machine while under the influence of drugs, alcohol, or any medication that could affect your ability to use it properly.

Dress properly. Wear heavy long pants, boots and gloves. Do not wear loose clothing, short pants, and jewelry of any kind. Secure long hair so it is above shoulder level. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.

Use safety equipment. Always wear eye protection. Safety equipment such as a dust mask, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.

Check your machine before starting it. Keep guards in place and in working order. Make sure all nuts, bolts, etc. are securely tightened. Disengage all clutches and shift into neutral before starting the engine.

Never operate the machine when it is in need of repair or is in poor mechanical condition. Replace damaged, missing or failed parts before using it. Check for fuel leaks. Keep the machine in safe working condition.

Never tamper with safety device. Check their proper operation regularly.

Do not use the machine if the engine's throttle control does not turn it on or off. Any gasoline powered machine that can not be controlled with the engine throttle control is dangerous and must be replaced.

Form a habit of checking to see that keys and adjusting wrenches are removed from machine area before starting it. A wrench or a key that is left attached to a rotating part of the machine may result in personal injury.

Stay alert, watch what you are doing and use common sense when operating the machine.

Do not overreach. Do not operate the machine while barefoot or when wearing sandals or similar lightweight footwear. Wear protective footwear that will protect your feet and improve your footing on slippery surfaces. Keep proper footing and balance at all

times. This enables better control of the machine in unexpected situations.

Avoid accidental starting. Be sure the engine's throttle control is off before transporting the machine or performing any maintenance or service on the unit. Transporting or performing maintenance or service on a machine with its throttle control on invites accidents.

Fuel safety

Fuel is highly flammable, and its vapors can explode if ignited. Take precautions when using to reduce the chance of serious personal injury.

When refilling or draining the fuel tank, use an approved fuel storage container while in a clean, well-ventilated outdoor area. Do not smoke, or allow sparks, open flames or other sources of ignition near the area while adding fuel or operating the unit. Never fill fuel tank indoors.

Keep grounded conductive objects, such as tools, away from exposed, live electrical parts and connections to avoid sparking or arcing. These events could ignite fumes or vapors.

Always stop the engine and allow it to cool before filling the fuel tank. Never remove the cap of the fuel tank or add fuel while the engine is running or when the engine is hot. Do not operate the machine with known leaks in the fuel system.

When practical, remove the machine from the truck or trailer and refuel it on the ground. If this is not possible, then refuel the machine on a trailer with a portable container, rather than from a fuel dispenser nozzle.

Loosen the fuel tank cap slowly to relieve any pressure in the tank.

Keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete. Do not use a nozzle lock- open device.

Never over fill fuel tank. Fill tank to no more than 12.5mm (1/2") below the bottom of the filler neck to provide space for expansion as the heat of the engine and/or sun cause fuel to expand.

Replace all fuel tank and container caps securely and wipe up spilled fuel. Never operate the unit without the fuel cap securely in place.

Avoid creating a source of ignition for spilled fuel. If fuel is spilled, do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until fuel vapors have dissipated. Serious personal injury can occur when fuel is spilled on yourself or your clothes which can ignite. Wash your skin and change clothes immediately.

Store fuel in containers specifically designed and approved for this purpose.

Never fill containers inside a vehicle or on a truck or trailer bed with a plastic liner. Always place containers on the ground away from your vehicle before filling.

Store fuel in a cool, well-ventilated area. Safely away from sparks, open flames or other sources of ignition.

Never store fuel or machine with fuel in the tank inside a building where fumes may reach a spark, open flame, or other sources of ignition, such as a water heater, furnace, clothes dryer and the like. Allow the engine to cool before storing in any enclosure.

Machine use and care

Never pick up or carry a machine while the engine is running.

Do not force the machine. Use the correct machine for your application. The correct machine will do the job better and safer at the rate for which it was designed.

Do not change the engine governor settings or over-speed the engine. The governor controls the maximum safe operating speed of the engine.

Do not put hands or feet near rotating parts. Avoid contact with hot fuel, oil, exhaust fumes and hot surfaces. Do not touch the engine or muffler. These parts get extremely hot from operation. They remain hot for a short time after you turn off the unit. Allow the engine to cool before doing maintenance or making adjustments.

After striking a foreign object, stop the engine, remove the wire from the spark plug, thoroughly inspect the machine for any damage, and repair the damage before restarting and operating the machine.

If the machine should start to make an unusual noise or vibration, immediately shut off the engine, disconnect the spark plug wire, and check for the cause. Unusual noise or vibration is generally warning of trouble.

Use only attachments and accessories approved by the manufacturer. Failure to do so can result in personal injury.

Maintain the machine. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the machine's operation. If damaged, have the machine repaired before use. Many accidents are caused by poorly maintained equipment.

Keep the engine and muffler free of grass, leaves, excessive grease or carbon build up to reduce the chance of a fire hazard.

Never douse or squirt the unit with water or any other liquid. Keep handles dry, clean and free from debris. Clean after each use.

Observe proper disposal laws and regulations for gas, oil, etc. to protect the environment.

Store idle machine out of the reach of children and do not allow persons unfamiliar with the machine or these instructions to operate it. Machine is dangerous in the hands of untrained users.

Service

Before cleaning, repair, inspecting, or adjusting shut off the engine and make certain all moving parts have stopped. Always make sure the engine's throttle control is in its STOP position. Disconnect the spark plug wire, and keep the wire away from the plug to prevent accidental starting.

Have your machine serviced by qualified repair personnel using only identical replacement parts. This will ensure that the safety of the machine is maintained.

4.2 Specific Safety Rules

Do not operate without wearing adequate winter outer garments.

Do not use the machine on a roof.

Do not run the engine indoors, except when starting the engine and for transporting the snow blower in or out of the building. Open the outside doors; exhaust fumes are dangerous.

Always check overhead and side clearances carefully before operation. Always be aware of traffic when operating along streets or curbs.

Thoroughly inspect the area to be worked. Keep the working area clean and free of toys, doormats, newspapers, sleds, boards, wires and other foreign objects, which could be tripped over or thrown by the auger/impeller. Check for weak spots on docks, ramps or floors.

Plan your snow-throwing pattern to avoid discharge toward people or areas where property damage can occur.

Do not operate near drop-offs, ditches, or embankments. Machine can suddenly turn over if a wheel is over the edge of a cliff or ditch, or if an edge caves in.

Keep all bystanders, children, and pets at least 23m (75 feet) away. If you are approached, stop the unit immediately.

Use a grounded three-wire extension cord and receptacle for all machines with electric start engines.

Check clutch and brake operation frequently. Adjust and service as required. All motion of drive wheels and auger/impeller must

stop quickly when control levers are released.

Let engine and machine adjust to outdoor temperature before starting to clear snow.

Stay alert for hidden hazards or traffic.

Do not overload machine capacity by attempting to clear snow at too fast of a rate.

Do not throw snow any higher than necessary.

Adjust auger housing height to clear gravel or crushed rock surfaces. Exercise extreme caution when operating.

Exercise caution to avoid slipping or falling, especially when operating in reverse. Never operate machine at high transport speeds on slippery surfaces. Always look down and behind before and while backing.

Do not operate on steep slopes. Do not clear snow across the face of slopes. Keep all movement on slopes slow and gradual. Do not make sudden changes in speed or direction. Use a slow speed to avoid stops or shifts on slopes. Avoid starting or stopping on a slope. Do not park machine on a slope unless absolutely necessary. When parking on a slope, always block the wheels.


Disengage power to the auger/impeller when transporting or not in use.

Disengage all control levers and stop engine before you leave the operating position (behind the handles). Wait until the auger/impeller comes to a complete stop before unclogging the chute assembly, making any adjustments, or inspections.

Hand contact with the rotating impeller inside the discharge chute is the most common cause of injury associated with snow blowers. Do not unclog chute assembly while engine is running. Shut off engine and remain behind handles until all moving parts have stopped before unclogging. Never put your hand in the discharge or collector openings. Always use the clean-out tool provided to unclog the discharge opening.

5. Contents Supplied

The snow blower comes partially assembled and is shipped in carefully packed carton. After all the parts have been removed from the carton, you should have:



All references to the left or right side of the snow blower are from the operator's position.


1. Snow blower Unit
2. Discharge Chute
3. Handlebars
4. Shift Rod
5. Operator's Manual & Engine Manual
6. Engine Hardware Bag
7. Snow blower Hardware Bag, including

	M10 X 40	X 2	A
	M8 X 45	X 4	B
	M8 X 20	X 2	C
	M8 X 25	X 2	
		X 2	
	M8 X 40	X 2	D
		X 1	E
	M8	X 1	F
		X 4	G
		X 4	
	6 X 37	X 3	H


6. Assembly

Following the assembly directions below, you will assemble the snow blower in a few minutes.

Handlebars



1. Align the holes in the handle with the side plates and secure lower handle with the screws and the washers until they are finger tight.
2. Keep the lower handle level and tighten all four screws.



3. Raise the handlebars into operation position and secure the handlebars with M8X45 screws, washers and nuts until they are finger tight.
4. Ensure that the handles are at the same height, and then tighten the fasteners securely.

Tires

The tires are over-inflated at factory for shipping purposes. Check the pressure in the tires. Reduce or increase equally in both tires to the manufacturer's recommended pressure.



! WARNING



Under any circumstance do not exceed manufacturer's recommended pressure. Excessive pressure when seating beads may cause tire/rim assembly to burst with force sufficient to cause serious injury. Refer to side wall of tire for recommended pressure. Equal tire pressure should be maintained at all times. If the tire pressure is not equal in both tires, the machine may not travel in a straight path and the scraper blade may wear unevenly. Keep tires free of gasoline and oil, which can harm rubber.

Add oil according to Engine Manual packed separately with your unit.

Skid Shoes

1. Move the machine to a level surface.
2. Support the auger blades so that they are 3mm (1/8") off the ground.
3. Check the scraper blade adjustment. The scraper blade should be 3mm (1/8") above and parallel to a level ground. To adjust the scraper blade, loosen the mounting screws, level the scraper blade, and tighten the mounting screws.
4. Attach both skid shoes to the auger side plates with the screws and nuts. Move the skid shoes down as far as possible. Be sure both skid shoes are adjusted evenly. Tighten securely.




	M8 X 20	X 2
	M8 X 25	X 2
		X 2

C


Discharge Chute

1. Grease underside of discharge chute ring (if not already greased).
2. Install discharge chute over opening in the auger housing. Orient the chute and pedestal to its most vertical position and tighten pedestal hardware.
3. Connect the deflector control cable eyelet to the chute deflector as shown. Tighten securely. Eyelet will be loose on shoulder bolt.
4. Insert the cable fitting into the cable bracket on discharge chute.
5. Adjust and tighten jam nut.




Speed Shift Linkage

1. After the shift rod with a flat washer has been inserted through the hole in the shift arm, add the other flat washer on the shift rod, and secure with a clevis pin.




2. Lift up on the shift rod. Loosen the jam nut under the trunnion and thread the trunnion along the shift rod until it fits into the hole in the shift lever. Tighten the jam nut and install the washer and M8 nut. Tighten securely.



Chute Clean-Out Tool


Fasten the clean-out tool to the mounting clip on the rear of the auger housing.



Replacement Shear Pins

Occasionally a foreign object may enter the auger/impeller housing and jam the auger breaking shear pins which secure the auger to the shaft. This allows auger to turn freely on the shaft which may help prevent damage to gear drive.

1. Align shear pin holes in auger with shear pin holes in shaft.
2. Drive shear pin through hole (if shear pin was broken this will drive remaining part from shaft).
3. Secure shear pin with clevis pin.





Two pairs of replacement auger shear pins and clevis pins are included with your snow blower. Store them in a safe place until needed.

Spare Roll Pins


The impeller is secured to the impeller shaft with roll pins.

Three 6x37 roll pins for impeller are supplied as spare in the hardware bag. Store them in a safe place until needed.



7. Know Your Snow blower

7.1 Features and Controls



Speed Shift Lever

The speed shift lever has 8 positions: 6 forward speeds and 2 reverse. To change speeds, move the speed shift lever to the desired position. The lever locks in a notch at each speed selection.

WARNING

Always release the drive clutch lever before changing speeds. Failure to do so will result in damage to the snow blower.

Slower speeds are for heavier snow and faster speeds are for light snow and transporting the snow blower. It is recommended that you use a slower speed until you are familiar with the operation of the snow blower.

If the engine slows down under a load or the wheels slip, shift the machine into a lower gear.


If the front of the machine rides up, shift the machine into a lower gear. If the front continues to ride up, lift up on the handles.

4-Way Chute Directional Control

Hold the trigger cap down to use the joystick to move the discharge chute and the chute deflector. Release the trigger cap to lock the discharge chute and chute deflector into position.

To change the chute position, hold the trigger cap down on the joystick and pivot the joystick to the right or to the left.

To change the angle/distance which snow is thrown, hold the trigger cap down on the joystick and pivot the joystick forward or backward.



Drive Clutch Lever

Squeeze the clutch lever against the handgrip to engage the wheel drive. Release to disengage.

WARNING

Always release the drive clutch lever before changing speeds. Failure to do so will result in damage to the snow blower.



Auger Clutch Lever

Squeeze the clutch lever against the handgrip to engage the auger and start snow throwing action. Release to disengage.



When both auger clutch lever and drive clutch lever are engaged, the drive clutch lever will lock the auger clutch lever in the engaged position. This allows you to release your left hand from the handle and adjust the discharge chute direction without interrupting the snow throwing process.

Scraper Blade & Skid Shoes

The scraper blade allows better contact with the surface being cleared. It also prevents damage to the housing from normal use.

The skid shoes are located on each side of the auger housing and control the distance between the scraper blade and the ground. Adjust skid shoes equally to keep the scraper blade level with the ground.


The scraper blade & skid shoes are subject to wear and damage. Both scraper blade and skid shoes are adjustable to compensate for wear. They should be checked and adjusted periodically. Replace when necessary.

WARNING

Damage to auger housing will result if scraper blade wears down too far.

Both scraper blade and skid shoes have two wear edges. When one side wears out, they can be rotated 180° to use the other edge.

Shear Pins



The augers are secured to the auger shaft with shear pins and clevis pins. If the auger should strike a foreign object or ice jam, the snow blower is designed so that the pins may shear, preventing damage to any other components. If augers will not turn, check to see if the pins have sheared. Replace the shear pins if necessary.

WARNING

Do not substitute. Use only original equipment shear pins as supplied with your snow blower.

Auger

When engaged, the augers rotate and draw snow into the auger housing.

Discharge Chute

Snow drawn into the auger housing is discharged out the discharge chute.

Chute Clean-Out Tool

WARNING

Never use your hands to clear a clogged discharge chute. Shut off engine and remain behind handles until all moving parts have stopped before unclogging.

The chute clean-out tool is conveniently fastened to the rear of the auger housing with a mounting clip. Should snow and ice become lodged in the discharge chute during operation, proceed as follows to safely clean the discharge chute and chute opening:

1. Release the auger clutch lever and shut off the engine.
2. Remove the clean-out tool from the clip which secures it to the rear of the auger housing.
3. Grasp the tool firmly by the handle and push and twist the tool into the discharge chute to dislodge the blockage.

4. Refasten the clean-out tool to the mounting clip on the rear of the auger housing.
5. Make sure the discharge chute is pointed in a safe direction (no vehicles, buildings, people, or other objects are in the direction of discharge). Restart the engine. While standing in the operator's position (behind the snow blower), engage the auger control for a few seconds to clear any remaining snow and ice from the auger housing and the discharge chute.

Headlight (if so equipped)

The headlight provides added safety in low-visibility conditions. Turn the headlight switch to the ON position to activate.



Heated Grips (if so equipped)




WARNING

It is recommended that you wear gloves when using the heated grip. If the heated grip becomes too hot, turn it off.

To activate the heated grips, move the switch into ON position.




Drift Cutters (if so equipped)



Drift cutters break up snow drifts that are taller than the auger housing and direct the snow into the auger. Store the drift cutters on the auger housing when not in use. Reposition drift cutters so they face forward as shown. Wing nuts should be fastened on the outside of the auger housing.

Steering Triggers (if so equipped)



Steering triggers are used to assist in steering the snow blower. The triggers are located on the underside of each handlebar. When a trigger is squeezed, it disengages the drive wheel on that side and allows the snow blower to turn in that direction. With the drive clutch engaged, squeeze the right trigger to turn right and squeeze the left trigger to turn left.

It is easier to maneuver a non- running snow blower with both triggers held in simultaneously.

Fuel Shutoff Valve

Always operate the snow blower with the fuel shut-off valve in the OPEN position. Close the valve when you do not use the machine.

Throttle Lever

Move the throttle lever to the right to increase the engine speed; move it to the left to decrease the engine speed. Move the throttle lever to the STOP position to stop the engine.

Choke

Engage choke by rotating lever to FULL position whenever you are starting a cold engine. As engine warms up, gradually rotate the choke to the OFF position.

Do not use choke to start a warm engine.



WARNING

Never use choke to stop engine.

Primer

Press the primer to pump additional fuel from the carburetor to the cylinder for improved cold weather starting.

Recoil Starter

The recoil starter is on the back side of the engine. Pull the recoil starter handle to start the engine.

Safety Ignition Switch (if so equipped)

Insert the safety ignition key for engine to start and run. To stop the engine, remove the key.

ON/OFF switch (if so equipped)

Used to stop the engine. Move switch to OFF position to stop engine. Place switch in ON position for engine to start and run.

Ignition Switch (12V DC electric start)

The ignition switch is operated by a removable key which has 3 positions of STOP, RUN and START.

Electric Starter & Start Button (if so equipped)

The electric starter will start a properly choked and cranked engine when the key is turned (12V DC) or start button (120V or 230V AC) is pushed.

To start the machine, connect the electric starter to an electric power source with an approved extension cord and press the start button.





WARNING

Thoroughly inspect the electrical cord before using the machine. If the cord is damaged, do not operate the machine. Replace or repair the damaged cord immediately.

Connect extension cord to the electric starter plug-in first and then to a power outlet; disconnect the extension cord from the power outlet first and then from the machine.

To prevent damaging the electric starter, do not run it more than 5 continuous seconds each time you try to start. Wait 10 seconds between each attempt.

Track Lock Lever (if so equipped)



The track lock lever is used to select the position of the auger housing and the method of track operation. Move the lever to the right then forward or backward to one of the three positions.

Deep Cutting - Locks the front end of the snow blower down to the ground for hard-packed or icy snow conditions.

Normal - Allows the tracks to be suspended independently for continuous ground contact.

Transport - Raises the front end of the snow blower for easy transport. Using proper caution, this position may also be used on many gravel driveways to clear snow while leaving gravel undisturbed.

7.2 Adjustments

Skid Shoes

Position the skid shoes based on surface conditions. For removal of snow in normal conditions, such as a paved driveway or sidewalk, place skid shoes in the higher position to give a 3mm (1/8") clearance between the scraper blade and the ground. Use a middle or lower position when the area to be cleared is uneven, such as a gravel driveway.


WARNING

It is not recommended to operate the snow blower on gravel as it can easily pick up and throw by the impeller, causing personal injury or damage to the snow blower and surrounding property.

If you choose to operate the snow blower on a gravel surface, use extra caution and keep the skid shoes in position for maximum clearance between the ground and the scraper blade.

WARNING

Always adjust skid shoes after adjusting scraper blade to prevent premature wear to scraper blade or damage to auger housing.



To adjust the skid shoes:

1. Loosen the four hex nuts (two on each side) and carriage bolts. Move skid shoes to desired position.

2. Make sure the entire bottom surface of skid shoe is against the ground to avoid uneven wear on the skid shoes.
3. Retighten nuts and bolts securely.


Auger Clutch and Drive Clutch

When auger clutch lever or drive clutch lever is released and in the disengaged position, the cable should have very little slack.

Auger must stop within 5 seconds when the auger clutch lever is released. If auger clutch does not engage or disengage properly, adjust auger clutch before operation.


If the snow blower's drive is disengaging intermittently during operation, or it drives when you release the drive clutch lever, adjust the drive clutch before operation.

Both auger clutch and drive clutch can be adjusted at either end of their control cables.



1. Loosen adjusting nuts on cable support bracket.
2. Slide the control cable up or down by threading adjusting nuts to increase cable tension or provide more slack.
3. Tighten nuts after proper adjustment is achieved.

Chute Lock Latch



If the discharge chute does not lock into the desired position or does not unlock so that chute rotates freely, adjust the chute lock latch.


If the chute does not lock:

Loosen the cable by loosening the rearward adjustment nut, and tightening the forward adjustment nut against the bracket until the lock latch fully engages the gear teeth.

If the chute does not unlock:

Tighten the cable by loosening the forward adjustment nut, and then tightening the rear adjustment nut against the bracket until all cable slack is removed.


Deflector Control




If deflector does not follow full range of travel, adjust the control cable at either end of it.

1. Hold the trigger cap down and push joystick all the way forward. Release the trigger cap.
2. Loosen adjusting nuts on cable support bracket either underneath the control panel or on the chute deflector.
3. To adjust the deflector lower, slide cable down. Tighten bottom nut.
4. To adjust deflector higher, slide cable up. Tighten top nut.
5. Check travel and repeat adjustment as necessary.

Track Tension



Over time the track can stretch. If the machine is pulling to the left when a straight path is desired, tighten the left track. If the unit is pulling to the right, tighten the right track. To adjust the tension, tighten the flange lock nut on the front of track side plate. This pulls the J bolt attached to the axle and tightens the tracks.



Check the track tension by applying pressure on the track midway between the upper and rear track rollers.


Deflection should be approximately 10mm.

If deflection is excessive, tighten the track tension.


8. Operation

8.1 Freewheeling and Self-Propelling

Left wheel equipped with the axle lock pin can be completely released by removing the pin and installing it in the outer axle hole. Unlock the left wheel to allow for easier turning of the unit.



To unlock the left wheel, remove the pin from the inner hole and insert the axle pin through the outer axle hole, but not through the wheel hub.



To lock the left wheel, insert the pin through the wheel hub and the inner axle hole.

8.2 Starting and Stopping the Engine

WARNING

Before starting the engine, check engine oil level and ensure the engine is serviced as described in the Engine Manual with the snow blower.

Cold Start – Electric Starter (120V or 230V AC) (if so equipped)

The engine is equipped with both A.C. electric starter and a recoil starter. The electric starter is equipped with a three-wire power cord and plug and is designed to operate at the voltage shown in the label.

 WARNING

Do not use the electric starter if your household voltage is different from the one shown on the electric starter.

1. Insert safety ignition key into ignition slot until it clicks. Do not turn the key.
2. Be sure fuel shutoff valve is in the OPEN position.
3. Move choke control to FULL position.
4. Push the primer 2 or 3 times. When temperature is below -25°C (15°F), additional priming may be needed. When temperature is above 10°C (50°F), priming is not necessary.

Over priming may cause flooding, preventing the engine from starting.

If you do flood the engine, wait a few minutes before attempting to start and do not push the primer.

Some snow engine is not equipped with primer as priming is not needed for such engine.

5. Connect the extension cord to the engine.
6. Plug the other end of the extension cord into a three-wire grounded receptacle.
7. Push starter button until engine starts.

 WARNING

To prevent damaging the electric starter, do not run it more than 5 continuous seconds each time you try to start. Wait 10 seconds between each attempt.

8. When the engine starts, release the starter button and slowly move the choke control to the OFF position.
9. Disconnect the extension cord from the receptacle first, then from the engine.

Cold Start – Electric Starter (12V DC) (if so equipped)

1. Be sure fuel shutoff valve is in the OPEN position.
2. Move choke control to OFF position.
3. Push the primer 2 or 3 times. When temperature is below -25 °C (15 °F), additional priming may be needed. When temperature is above 10°C (50°F), priming is not necessary.

Over priming may cause flooding, preventing the engine from starting.

If you do flood the engine, wait a few minutes before attempting to start and do not push the primer.

Some snow engine is not equipped with primer as priming is not needed for such engine.

4. Turn ignition key to the START position until engine starts.

 WARNING

To prevent damaging the electric starter, do not run it more than 5 continuous seconds each time you try to start. Wait 10 seconds between each attempt.

5. When the engine starts, release the ignition key into RUN position and slowly move the choke control to the FULL position.

Cold Start - Recoil Starter

1. Be sure fuel shutoff valve is in the OPEN position.
2. Place ON / OFF switch in ON position.
3. Rotate choke control to OFF position.
4. Push the primer 2 or 3 times. When temperature is below -25 °C (15 °F), additional priming may be needed. When temperature is above 10°C (50°F), priming is not necessary.

Over priming may cause flooding, preventing the engine from starting.

If you do flood the engine, wait a few minutes before attempting to start and do not push the primer.

5. Grasp recoil starter handle and pull rope out slowly until it pulls harder. Let rope rewind slowly.
6. Pull rope with a rapid continuous full arm stroke. Do not allow starter rope to snap back.
7. Repeat steps 5 and 6 until engine starts.
8. When the engine starts, release the recoil starter handle and slowly move the choke control to the FULL position.

Warm Start

Follow the steps above, keeping the choke control in the OFF position and do not use primer.

Allow the engine to warm up for a few minutes. The engine will not develop full power until it has reached normal operating temperature.

In snowy and cold conditions, some controls and moving parts may freeze. Do not use excessive force when trying to operate frozen controls. If you have difficulty operating any control or part, start the engine and let it run for a few minutes.

8.3 Snow Throwing Tips

It is easier and more efficient to remove snow immediately after it falls.

The best time to remove snow is the early morning. At this time the snow is usually dry and has not been exposed to the direct sun and warming temperatures.

Slightly overlap each successive path to ensure all snow will be removed.

For large areas, start in the middle and throw snow to each side, so snow is not cleared more than once.

For extremely heavy snow, reduce the width of snow removal by overlapping previous path and moving slowly.

Throw snow downwind whenever possible.

Keep engine clean and clear of snow during use. This will help air flow and extend engine life.

After snow-throwing is completed, let the engine run for a few minutes to help dry off the moisture on the engine and prevent moving parts from freezing. Engage the auger/impeller to clear any remaining snow from inside the housing. Rotate the discharge chute to prevent it from freezing. Stop the engine, wait for all moving parts to stop, and remove all ice and snow from the snow blower. With the engine off, pull the recoil starter handle several times to prevent the recoil starter from freezing up.

8.4 Traveling

To travel from one work area to another:

1. Set throttle to slow or part-throttle position.
2. On wheeled model, press down on handle bars enough to raise front of unit slightly off surface; on tracked model, move the track lock lever into the transport position.
3. Engage drive clutch without engaging auger clutch.

8.5 Transport

WARNING

Always shut off engine, remove key, and close fuel shut-off valve when transporting unit on a truck or trailer. Do not transport machine while engine is running.

Use extra care when loading or unloading unit onto trailer or truck.

Secure unit chassis to transport vehicle. Never secure from rods or linkages that could be damaged.


9. Maintenance

Engine

Refer to the Engine Operator's Manual.

Lubrication


Auger Gearbox.




The gearbox was filled with lubricant to the proper level at the factory. Unless there is evidence of leakage or service has been performed on the gearbox, no additional lubricant should be required. If lubricant is required, use GL-5 or GL-6, SAE85-95, EP gear oil lubricant. Do not use synthetic oil.

General Lubrication

Lightly lubricate all moving parts of the machine at the end of the season or every 25 operating hours.





Do not allow grease or oil get on friction disc, friction plate or belts. Do not excessively oil the machine; extra oil may enter the traction drive and cause the traction drive belt to slip.

When lubricating auger shaft, remove shear pins to apply oil inside the shaft and around spacers and flange bearings found at either end of the shaft.

Remove the wheels to apply grease to wheel shaft.

Battery (if so equipped)



WARNING

Battery is maintenance-free. Do not tamper with or attempt to open battery.

Keep battery and its terminals clean

1. Remove battery cover.
2. Detach the negative (black) battery cable from the battery first to prevent a short circuit, then the positive (red) battery cable.
3. Take the battery out of the tray.
4. Remove corrosion from battery terminals and cable connections with a wire brush, then wash with weak baking soda solution.
5. Apply a thin coat of grease or petroleum jelly to terminals and cable ends to retard corrosion.
6. Attach and tighten the positive (red) battery cable first, then the negative (black) battery cable.
7. Place the battery on the tray and install the cover.

Off-Season Storage



WARNING

Refer to the Engine Manual for information on storing your engine.

At the end of the season or if the snow blower will not be used for 30 days or longer, follow the storage instructions below.


1. Run the engine until the fuel lines and carburetor are empty and it stops due to lack of fuel.
2. Remove the safety ignition key and allow the engine to cool.
3. Lubricate the machine as instructed.
4. Clean the exterior of the engine and the snow blower thoroughly.
5. Touch up all rusted or chipped paint surfaces; sand affected areas before painting, and use a rust preventative to prevent the metal parts from rusting.
6. Tighten all loose screws, bolts, and locknuts. Repair or replace any damaged parts.
7. Cover the machine and store it in a clean, dry place out of the reach of children.

10. Service

10.1 Belt Replacement


If the auger belt becomes worn, oil-soaked, or otherwise damaged, proceed as follows to replace the belt.

1.To prevent spillage, remove all fuel from tank by running engine until it stops. Remove the key to avoid unintended starting and allow unit to cool completely.



2.Remove the three bolts, spring washers and flat washers that hold the discharge chute.



3.Remove the auger assembly.




4.Lightly poke the three flappers towards the outside until there is enough clearance to remove the belt. Remove the belt.

5.Reattach the new belt, return the three flappers to their original positions, the clearance is about 2-3mm.

6.Carefully pivot the snow blower up and forward so that it rests on the auger housing.



7.Remove the frame cover(s) from the underside of the snow blower by removing the screws which secure the cover(s).



8.Remove the belt(s) from around the auger pulley, and slip the belt(s) between the support bracket and the auger pulley.


9.Replace the auger belt(s) by following instructions in reverse order.

Drive Belt

If the drive belt becomes worn, oil-soaked, or otherwise damaged, proceed as follows to replace the belt.

1. To prevent spillage, remove all fuel from tank by running engine until it stops. Remove the key to avoid unintended starting and allow unit to cool completely.

2. Remove the two screws that hold the belt cover in place and set the cover aside.




3. Remove the belt as follows.

- Roll the auger belt(s) off the engine pulley.
- Pivot the idler pulley toward the right to relieve tension.
- Lift the drive belt off engine pulley.

4. Carefully pivot the snow blower up and forward so that it rests on the auger housing.

5. Remove the frame cover(s) from the underside of the snow blower by removing the screws which secure the cover(s).




6. Slip the drive belt off the pulley and between friction wheel and friction wheel disc.

7. Remove and replace belt in the reverse order.

Holding down the drive clutch lever will ease reinstallation of the belt.

If an assistant is available, you can also separate the auger housing from the frame assembly to replace belts.



1. Shut off engine, remove key, disconnect spark plug wire and allow unit to cool completely.
2. Remove belt cover.
3. Remove chute gear cover and disconnect chute lock cable, deflector cable and chute rod.
4. Remove bottom cover to avoid bending it when tipping unit apart.
5. Remove the screws securing auger housing to the frame (two on each side). Tip auger housing and frame apart.
6. Replace auger belt or drive belt.
7. Tip auger housing and frame back together and secure with screws


Holding down the auger clutch lever will ease reconnection of the auger housing and frame.

8. Place belt(s) onto engine sheave(s).
9. Reconnect chute lock cable, deflector cable and chute rod.
10. Replace chute gear cover and belt cover.


10.2 Friction Wheel Replacement

If the snow blower fails to drive with the drive clutch engaged, and performing the clutch control cable adjustment fails to correct the problem, the friction wheel may need to be replaced.


1. To prevent spillage, remove all fuel from tank by running engine until it stops. Remove the key to avoid unintended starting and allow unit to cool completely.
2. Carefully pivot the snow blower up and forward so that it rests on the auger housing.
3. Remove the frame cover(s) from the underside of the snow blower by removing the screws which secure the cover(s).




4. On wheeled model, carefully remove the hex nut which secures the hex shaft to the snow blower frame and lightly tap the shaft's end to dislodge the ball bearing from the right side of the frame. Be careful not to damage the threads on the shaft.




Remove the other bearing from the left side of the frame by removing the snap ring.




Disassemble one chain pitch from left and right chain, remove the two chains.



Loosen the two bolts securing the pulley. Push the pulley down.




Carefully position the hex shaft downward and to the left before carefully sliding the friction wheel assembly off the shaft.




On tracked model, remove the three bolts, bearing seat, ball bearing and bushing from the left-hand side of the frame. Be careful not to damage the threads on the shaft.


Pry the shift fork up



Remove the three bolts, bearing seat, ball bearing and bushing from the right-hand side of the frame.




Disassemble one chain pitch from left and right chain, remove the two chains.




Loosen the two bolts securing the pulley.

Push the pulley down.




Carefully position the hex shaft downward and to the left before carefully sliding the friction wheel assembly off the shaft.



Remove small flat washer, minor sprocket combination, gear, key, gear ring assembly and big flat washer, then remove the friction wheel.

5. After replace the new friction wheel, follow the previous steps in reverse order to reassemble.

If you only want to replace the rubber ring, proceed as follows:



1. Remove the eight screws which secure the friction wheel's side plates together.
2. Remove the rubber ring from between the plates.
3. Reassemble the side plates with a new rubber ring

When reassembling the friction wheel assembly, make sure that rubber ring is centered and seated properly between the side plates. Tighten each screw only one rotation before turning the wheel clockwise and proceeding with the next screw on the other side of the wheel. Repeat this process several times to ensure the plates are secured with equal force between 90N.m(66 ft- lbs) and 130N.m(96 ft-lbs).

4. Slide the friction wheel assembly back onto the hex shaft. Make sure the shift lever pin is in place in the bearing housing. Follow the steps above in reverse order to reassemble components.

10.3 Charging Battery (if so equipped)

Follow the instructions below to charge battery:

1. Remove battery cover.

2. Disconnect negative (black) battery cable first, then positive (red) battery cable.
3. Take battery out of the tray and place it on a bench or other well-ventilated place.
4. Connect positive (+) lead of charger to positive (+) terminal, and negative (-) lead to negative (-) terminal.
5. Charge the battery at two and a half amps for ten hours.
6. Reinstall battery into unit.


11. Troubleshooting


Problem	Cause	Remedy
Electric starter does not turn (on models so equipped)	1. Extension cord not connected. 2. The extension cord is worn, corroded, or damaged. 3. The power outlet is not energized.	1. Connect the extension cord to the outlet and/or the machine. 2. Replace the extension cord. 3. Have a qualified electrician energize the outlet.
Engine fails to start	1. Choke not in CHOKE position. 2. Engine not primed. 3. Engine is flooded. 4. Fuel shut-off valve closed. 5. Throttle in STOP position or ON/OFF switch is OFF. 6. Spark plug wire loose or disconnected. 7. Fuel tank empty or stale fuel. 8. Faulty spark plug. 9. Safety ignition key is not inserted. 10. The engine oil level in the engine crankcase is too low or too high	1. Move choke to CHOKE position. 2. Prime engine as instructed in this manual. 3. Wait a few minutes before restarting, do not prime. 4. Open fuel shut-off valve. 5. Move throttle to FAST position or ON/OFF switch to ON Position. 6. Connect or tighten spark plug wire. 7. Fill tank with clean, fresh gasoline. 8. Clean, adjust gap, or replace. 9. Insert safety ignition key. 10. Add or drain oil to adjust the oil level in the engine crankcase.
Engine idles or runs roughly	1. Engine running on CHOKE. 2. Fuel tank is nearly empty or stale fuel. 3. Contaminated fuel supply. 4. Carburetor out of adjustment. 5. Engine over-governed. 6. The fuel shutoff valve is not completely open or blockage in fuel line. 7. Spark plug wire loose. 8. Faulty spark plug. 9. The engine oil level in the engine crankcase is too low or too high.	1. Move choke lever to RUN position. 2. Fill tank with clean, fresh gasoline. 3. Replace with clean fuel. 4. Contact qualified repair personnel. 5. Contact qualified repair personnel. 6. Open the fuel shutoff valve or clean fuel line. 7. Tighten spark plug wire. 8. Clean, adjust gap, or replace. 9. Add or drain oil to adjust the oil level in the engine crankcase.
The engine overheats	Carburetor not adjusted properly.	Contact qualified repair personnel.


Problem	Cause	Remedy
Excessive vibration	Loose parts or damaged parts.	Tighten all fasteners or replace damaged parts.
Loss of power	1. Spark plug wire loose. 2. Gas cap vent hole plugged. 3. Dirty or clogged muffler.	1. Tighten spark plug wire. 2. Clean or replace fuel cap. 3. Clean or replace muffler.
Loss of traction drive	1. Drive control cable not adjusted properly. 2. Drive belt loose or damaged. 3. Friction wheel worn.	1. Adjust drive control cable. 2. Replace drive belt. 3. Replace friction wheel.
Loss of snow discharge or slowing of snow discharge	1. Discharge chute clogged. 2. Augers or impeller jammed. 3. Auger control cable not adjusted properly. 4. Auger belt loose or damaged. 5. Shear pin(s) sheared. 6. Throttle not in FAST position when throwing snow. 7. Moving too fast to clear the snow. 8. Throwing too much snow. 9. Trying to remove extremely heavy or wet snow. 10. Auger is frozen in place.	1. Unclog discharge chute. 2. Remove debris or foreign object from augers or impeller. 3. Adjust auger control cable. 4. Replace auger belt. 5. Replace with new shear pin(s). 6. Move throttle to FAST position. 7. Shift into a lower gear. 8. Reduce speed and width of swath. 9. Do not overload with extremely heavy or wet snow. 10. Move unit to a warm place to thaw.
Discharge chute either does not lock into place or does not move	1. The discharge chute control not adjusted properly. 2. Chute assembly incorrectly assembled	1. Adjust the discharge chute control. 2. Disassemble chute control and reassemble as instructed in this manual.
Machine does not properly clear the snow from the surface	1. The skid shoes and/or scraper blade not adjusted properly. 2. The pressure in the tires is not equal.	1. Adjust the skid shoes and/or the scraper blade. 2. Check and adjust the pressure in one or both tires.

12. Exploded View & Parts List

GSBT33 Exploded View







GSBT33 Parts List

Part No.	Description	Qty	Part No.	Description	Qty
1	Left Auger Weldment	1	142	Swing Arm Assembly	1
2	FT Bolt M6x20	7	143	Friction Wheel Hub	1
3	Spring Washer 6	7	144	Friction Wheel	1
4	Flat Washer 6	7	145	Pawl Rotating Shaft	1
5	Screw M5x10	1	146	Auger Tensioner Spring	2
6	Left Gearbox Housing	1	147	Pawl Assembly	2
7	Pin 6x40	4	148	Friction Wheel Press Plate Gasket	1
8	Key 5x7.5x19	1	149	Friction Wheel Press Plate	2
9	Auger Shaft	1	150	Cylindrical Pin 8x16	6
10	Clip 1.8	11	151	Self-lubricating Bearing 15x17x10 mm	2
11	Worm Gear	1	152	Self-lubricating Bearing 13x15x10 mm	4
12	Shaft Sleeve	2	153	Welded Sprocket	2
13	Right Gearbox Housing	1	154	Stamped Bearing Housing 6201	2
14	Seal B22x35x70	2	155	Bearing 6201-2RS	2
15	Large Flat Washer	4	156	Retainer Sleeve	2
16	Right Auger Weldment	1	157	Flat Washer 13.5x20x1.8	2
17	Stamped Bearing Housing 6206	2	158	Gear Z18	2
18	Ball Bearing 6206-2RS	2	159	Cylindrical Pin 3x8	2
19	Locking Screw ST 8x16	20	160	Gear Z12	6
20	FT Bolt M6x25	2	161	Ring Gear Z42	2
21	Grease Nipple M10x1	1	162	Ring Gear Carrier	2
22	Auger Support Plate	1	163	Pin 4x14	6
23	Lock Nut M8	15	164	Inter-shaft Gasket	2
24	Extra Large Flat Washer 10	3	165	Nut M6	2
25	Bolt M8x20	5	166	FT Bolt M6x30	2
26	Ball Bearing 6001-2RS	1	167	B Type Spring Nut	2
27	Worm	1	168	Cable Connecting Rod	1
28	Key 5x45	1	182	Thick Lock Nut M10	2
29	Impeller Shaft	1	183	Compression Spring	1
30	Roll Pin 6x37	3	184	Right Gear Shift Lever Grip	1
31	Key 6x36 (Type C)	1	185	Gear Shift Lever	1
32	Roll Pin 4x25	1	186	Left Gear Shift Lever Grip	1
33	Gasket	1	187	Screw M5x12	1
34	Thrust Ball Bearing 51104	1	188	FT Bolt M10x60	1
35	Impeller Shaft Sleeve	1	189	Rubber Plug	1
36	Ball Bearing 61904-2RS	1	190	Dashboard	1
37	Rotary Shaft Lip Seal B20x35x7	1	191	Plastic Ring	1
38	Impeller Assembly	1	192	Screw ST4.2x19	2
39	Shave Plate	1	193	Right Joystick Housing	1
40	Flat Washer 8	6	194	Joystick Support Bracket	1
41	Lock Nut M8	25	195	Joystick, Right Half	1
42	Bolt M8x25	2	196	Joystick Head	1
43	Bolt M8x16	7	197	Screw ST4.2*16	4
44	Iron Skid Shoe	2	198	Joystick Torsional Spring Bracket	1
45	Bolt M8x30	1	199	Drawbar	1

Part No.	Description	Qty	Part No.	Description	Qty
46	Brake Tension Spring	1	200	Torsion Spring	1
47	Flat Washer 10	3	201	Joystick, Left Half	1
48	Ball Bearing 6004-2RS	1	202	Reamer Bolt M10x60	1
49	Bearing Housing	1	203	Left Joystick Housing	1
50	Brake Rocker Arm Plate	1	204	Stop Pawl	1
51	Screw M4x12	4	205	Pull Rod Bracket	1
52	Brake Pad	2	206	Underlay Plate	1
53	Auger Pulley	1	207	Rotating Fixing Frame Weldment	1
54	Brake Link Plate	1	208	FT Bolt (CVC) M8*16	2
55	Lock Nut M4	4	209	Light	1
56	FT Bolt M8x20	4	210	LED Light Shock-absorbing Rubber Pad	1
57	Belt 4LXA960	2	211	Light Holder	1
58	Extra Large Flat Washer 8	1	212	Screw ST4.8*16	3
59	Spring Washer 8	4	213	Locking Screw ST 8x16	4
60	FT Bolt M8x25	1	214	Sliding Sleeve	2
61	FT Bolt M8x40	4	215	Flat Washer 12	1
62	Large Flat Washer 8	6	216	Snap Ring 9	1
63	Support Tube	1	217	Switch	2
64	Steering Lock Cable	1	218	Left & Right Operation Handles Connecting Plate	1
65	Steering Control Cable	2	219	Furniture Screw M6x40	2
66	Rotating Claw	1	220	Interlock Cam	1
67	Rotating Torsion Spring	1	221	Pin 3x20	1
68	Flange Lock Nut M6	3	222	Blind Rivet 4x16	4
69	Bolt M10x50	1	223	Left Heated Handle (160mm)	1
70	Rotating Gasket	2	224	Auger Clutch Lever	1
71	Chute Rotate Head	1	225	Lever Mounting Bracket	2
72	Rotating Cable Bracket	1	226	Chute Adjustable Cable	1
73	Flange Lock Nut (Non-standard) M10	5	227	Handle Limit Block	2
74	Spring Guide Rod	1	228	Left Differential Shift Control Lever	1
75	Discharge Chute Return Spring	1	229	Steering Shift Control Cable	2
76	Cable Fixing Bracket	2	230	Arc Cup Head Bolt M8x45	4
77	Discharge Chute	1	231	Left Operation Handle	1
78	Clean-Out Tool Mounting Bracket	1	232	Thick Lock Nut M6	4
79	Screw ST5.5x13	2	233	FT Bolt M5x12	2
80	Auger Housing Weldment (Joystick Type)	1	234	Interlock Spring Plate	1
81	Plug	4	235	Thick Lock Nut M5	1
82	Chute Clean-Out Tool	1	236	Left Lock Rod Bracket	1
83	Stop Rod Torsion Spring	1	237	Interlock Rod Weldment	1
84	Stop Rod	1	238	Right Lock Rod Bracket	1
85	Deflector Adjusting Cable	1	239	Right Heated Handle (160mm)	1
86	Lock Washer	2	240	Right Operation Handle	1
87	Extension Spring	1	241	Right Differential Shift Control Lever	1
88	Base Plate II	1	242	Drive Clutch Lever Return Spring	1
89	Base Plate	1	243	Drive Clutch Lever	1
90	Base Plate I	1	244	Screw ST6.3x16	2

Part No.	Description	Qty	Part No.	Description	Qty
91	Locking Screw ST 6x12	20	245	Drive Control Cable	1
92	Right Engine Mounting Bracket	1	246	Bolt M6x40	2
93	Left Engine Mounting Bracket	1	247	Flange Bolt M8x70	2
97	Ball Bearing 6006-2RS	1	248	Plastic Sleeve	2
98	Driven Pulley Hub	1	249	Large Flat Washer 6	1
99	Driven Pulley Swing Plate	1	250	Bolt M8x20	2
100	Flange Lock Nut M16x1.5	1	251	Arc Washer M8	4
101	Locating Shaft	1	252	Dashboard Side Bracket	2
102	Cotter Pin 2.5x20	10	253	Lower Support Frame	1
103	Auger Tensioner Assembly	1	254	Thick Lock Nut M8	4
104	Auger Tensioner Bracket	1	255	Arc Washer 10	2
105	Bracket Plate	1	256	FT Bolt M10x40	2
106	Tensioner Arm	1	257	FT Bolt M10x20	2
107	Flat Washer 12(13.5)	3	258	Large Flat Washer 10	7
108	Engine Base Board	1	259	Screw ST4.2*13F	1
109	Bolt M8x16	4	260	Shaft Circlip 6	1
110	Extension Spring	1	301	FT Bolt M12x30	2
111	Thin Nut M8	1	302	Spring Washer 12	2
112	Key 6x6x45	1	303	Large Flat Washer 12	2
113	Belt Pulley	1	304	Drive Wheel Weldment	2
114	Engine Shaft Extension Washer	1	305	Shaft Bushing	2
115	Bolt (with Engine)	1	306	Driven Pulley	1
116	Spring Washer 12	1	307	Belt V10X835	1
117	Bolt M8x45	1	308	Gearbox Housing Weldment	1
118	Bushing Sleeve (Double A Belt)	1	309	Differential Shift Fork Support Shaft	1
119	FT Bolt M8x30	1	310	Adjusting Sleeve	2
120	Small Bushing Sleeve	1	311	Spring	2
121	Drive Belt Tensioner Assembly	1	312	Adjusting Sleeve 2	2
122	FT Bolt M8*35	1	313	Rubber Track 64x19x137	2
123	Belt Blocker	2	314	Pedal Weldment	1
124	Spacer	1	315	Chain 08B	2
125	Drive Belt Tensioner Assembly Bracket	1	316	Driven Sprocket Z21	2
126	Engine Belt Guard	1	317	Key 8x36 (Type A)	2
127	Gasoline Engine	1	318	Drive Shaft (Track Type)	2
128	Cable Roller	1	319	Right Triangular Track Support Plate Weldment	1
129	Cable Retainer	1	320	Left Triangular Track Support Plate Weldment	1
130	Roller Bushing	1	321	Tensioning Screw	2
131	Cable Bracket	1	322	Driven Shaft	1
132	Swing Plate	1	323	Track Support Wheel Insert	4
133	Gear Shifting Lever	1	324	Lock Nut M14	4
134	Nut M10	1	325	Guide Wheel Shaft Weldment	1
135	Rotating Shaft	1	326	Bolt M6x16	6
136	Shift Fork Shaft	1	327	Track Tensioner Support	2
137	Plastic Bushing	4	328	Tension Spring	2

Part No.	Description	Qty	Part No.	Description	Qty
138	Shift Fork	1	329	Track Adjuster Plate	4
139	Friction Wheel Shaft	1	330	Bushing Sleeve	4
140	Shaft Circlip 35	1	331	Track Tension Wheel	4
141	FT Bolt M6x10	8			

WARRANTY INFORMATION:

Please refer to our website for detailed warranty conditions and coverage.
For the most up-to-date and comprehensive warranty information, visit www.tmgindustrial.com